


ASSEMBLY INISTRUCTIONS

BQ1082


WEIGHT CAPACITY:20lbs




① × 1pc		② × 1pc		③ × 1pc				
④ × 1pc		⑤ × 1pc		⑥ × 1pc				
⑦ × 2pcs		⑧ × 1pc		⑨ × 2pcs				
Ⓐ × 12pcs	Ⓑ × 12pcs	Ⓒ × 6pcs	Ⓓ × 4pcs	Ⓔ × 2pcs	Ⓕ × 4pcs	Ⓖ × 32pcs	Ⓗ × 4pcs	
Ⓘ × 2pcs	Ⓝ × 2pcs	Ⓚ × 1pc	Ⓛ × 2pcs	Ⓜ × 2pcs	Ⓝ × 6pcs	Ⓞ × 2pcs	Ⓟ × 2pcs	Ⓠ × 1pc

ASSEMBLY INISTRUCTIONS


STEP1




STEP2



STEP3




STEP4




ASSEMBLY INSTRUCTIONS


STEP 5




STEP 6



STEP 7




STEP 8



ASSEMBLY INISTRUCTIONS

STEP13



STEP14

